

Main Assembly

Model :93220 EB 30/1 Electric Broom

	Number	Description	Qty Req.
12	K47624000	BRUSH-ROLLER PACKAGED	1
1	K40810020	PART-BOTTOM	1
2	K43240420	PUSHBUTTON WITH SPRING	1
3	K52501010	BEARING-LEFT USE K52501470	1
4	K44540010	TRANSMISSION	1
5	K46542590	BATTERY-NI/CD 7.2V/1.5AH ACCUMULATOR-PACKAGED	1
6	K73031290	SCREW	9
7	K63484270	BELT-TOOTHED	1
8	K40705980	USE K40706070TUBE-COMPLETE	1
9	K40705640	USE K40706060GRIP-HANDLE COMPLETE	1
10	K46237500	MOTOR-COMPLETE	1
11	TBD	MAINS ADAPTER	1
12	K47624010	BRUSH-ROLLER PACKAGED	1
13	K48800580	SET-ROLLER	1
14	K40705880	TANK-SWEEP COMPLETE	1
15	K46820920	ELECTRONICS-COMPLETE	1
16	K48224340	PARTS-ELECTRICAL SMALL, COMPLETE	1
17	K66304130	SWITCH	1
18	K66541970	CHARGER-BATTERY-RECCHAG ABLE (QUICK)	1
19	K55152760	WHEEL	2
20	K63431870	LOCK WASHER	2
21	K50087750	BEARING PLATE LEFT	1

Main Assembly, Model:93220 EB 30/1 Electric Broom

